

Canon EOS 1D Mark IV	200,386	XHCAN1D1V611	£708
Canon EOS 1D X	New Shutter	XHCAN1DX569	£2,850
Canon EOS 1D X	165,000	XHCAN1DX115	£2,514
Canon EOS 1D X	41,586	XSCAN1DX604	£3,000
Canon EOS 1D X	173,000	XSCAN1DX663	£2,940
Canon EOS 1D X Mark II	110,948	XSCAN1DX11517	£3,900
Canon EOS 1DS Mark III	51,680	XHCAN1DS063	£750
Canon EOS 1DS Mark III	151,822	XHCAN1DS111914	£870
Canon EOS 1DS Mark III	New Shutter	XSCAN1DS111948	£990
Canon EOS 5D Mark II Infrared	136,000	XHCAN5D1IR696	£600
Canon EOS 5D Mark III	33,745	XSCAN5D111391	£1,398
Canon EOS 5D Mark III	62,053	XSCAN5D111392	£1,398
Canon EOS 5D Mark III	235,858	XSCAN5D111625	£1,296
Canon EOS 5D Mark IV	27,118	XSCAN5D1V926	£2,640
Canon EOS 6D	2,897	XHCAN6D775	£660
Nikon D3	257,300	XSNIKD3845	£630
Nikon D3	264,050	XSNIKD3936	£630
Nikon D3S	521,300	XSNIKD3S498	£829
Nikon D4	94,610	XSNIKD4446	£2,040
Nikon D4	196,000	XSNIKD4844	£1,890
Nikon D4	111,434	XSNIKD4047	£2,040
Nikon D4	420,597	XSNIKD4451	£2,039
Nikon D4	164,784	XSNIKD4489	£1,998
Nikon D5	138,457	XSNIKD5421	£3,960
Nikon D7200 + MB-D15 Grip	5,575	XSNIKD7200683	£720
Nikon D750	47,601	XSNIKD750804	£1,170
Nikon D800	175,188	XSNIKD800024	£990
Canon 600mm f/4L IS		XSCAN600661	£3,000
Canon EF 100-400mm f/4.5-5.6L IS		XSCAN100400147	£648
Canon EF 16-35mm f/2.8L II		XRCAN163511487	£625
Canon EF 16-35mm f/2.8L II		XRCAN163511753	£690
Canon EF 180mm f/3.5L Macro		XSCAN180MAC171	£810
Canon EF 8-15mm f/4L Fisheye		XSCAN815387	£870
Canon EF Extender 2x II		XSCANEF2X11614	£192
Fuji 1.4 XF Extender		XSFUJXF14502	£216
Fuji 18-55mm f2.8-4 OIS XF		XSFUJ1855117	£438
Fuji 18-55mm f2.8-4 OIS XF		XSFUJ1855441	£480
Fuji 23mm f/1.4 XF		XSFUJ23624	£528
Fuji 35mm f/1.4 XF		XSFUJ35257	£354
Fuji 60mm f/2.4 Macro XF		XSFUJ60MAC925	£390
Leica 24mm f/2.8 Elmarit-M		XSLEI24855	£1,290
Lomo 32mm f/2.8 Minitar Leica M Fit		XSLOMO32555	£168
Nikkor 105mm f/1.4E ED		XSNIK10514372	£1,398

Nikkor 16-35mm f/4G ED VR	XSNIK1635572	£690
Nikkor 16-35mm f/4G ED VR	XSNIK1635879	£678
Nikkor 17-55mm f/2.8G AF-S DX	XSNIK1755034	£630
Nikkor 200-400mm f/4G IF-ED VR	XSNIK200400887	£2,154
Nikkor 24-70mm f/2.8G IF-ED	XSNIK2470155	£960
Nikkor 24-70mm f/2.8G IF-ED	XSNIK2470210	£870
Nikkor 24-70mm f/2.8G IF-ED	XSNIK2470744	£924
Nikkor 28mm f/1.8G	XSNIK2818003	£396
Nikkor 300mm f/2.8D AF-I IF-ED	XSNIK300857	£1,230
Nikkor 300mm f/4D ED AF-S	XSNIK300791	£594
Nikkor 35mm f/1.4G ED	XSNIK3514309	£1,074
Nikkor 400mm f/2.8G ED VR	XSNIK400738	£4,500
Nikkor 70-200mm f/2.8G ED VR	XSNIK70200403	£702
Nikkor 70-200mm f/2.8G ED VR II	XHNIK7020011642	£1,194
Nikkor 70-200mm f/2.8G ED VR II	XHNIK70200242	£1,194
Nikkor 70-200mm f/2.8G ED VR II	XHNIK70200292	£1,194
Nikkor 70-200mm f/4G ED VR	XHNIK70200848	£810
Nikkor 70-300mm f/4.5-5.6G IF-ED VR	XSNIK70300166	£528
Nikkor 80-200mm f/2.8D	XRNIK80200626	£480
Nikkor 80-400mm f/4.5-5.6G ED VR	XSNIK80400522	£1,560
Nikkor 85mm f/1.4G	XSNIK8514899	£1,020
Nikkor 85mm f/2.8D PC-E Micro	XSNIK85PCE925	£1,020
Nikon TC-17E II	XSNIKTC1711997	£198
Nikon TC-17E II	XSNIKTC17E020	£198
Nikon TC-20E II	XSNIKTC20E838	£204
Sigma 10-20mm f/4-5.6 EX DC Nikon fit	XSSIG1020575	£180
Sigma 50-150mm f/2.8 II DC HSM	XSSIG50150378	£294
Sigma 50mm f/1.4 DG Canon EF Fit	XSSIG50481	£210
Sigma 800mm f/5.6 APO EX DG HSM Nikon Fit	XSSIG800NIK192	£3,528
Sony 70-200mm f/4 G OSS	XSSON70200004	£834
Sony 70-200mm f/4 G OSS	XSSON70200629	£900
Canon BG-E6 Battery Grip	XSCANBGE6214	£60
Canon LC-5 Remote Set	XSCANLC5101	£119
WFT-E7B File Transmitter (ex-demo)	4960999810669	£347
Fuji VG-XT1 Battery Grip	XSFUJVGXT750	£108
Fuji X-T1 Vertical Grip	XSFUJGRIP906	£108
Fuji X-T10 MHG-XT10 Grip	XSFUJXT10GRIP123	£59
Genus 72mm 4-Stop Vario-ND Filter	XSGEN72ND1	£36
Interfit Strobies Battery Pack	XSINTSTR123	£84
Leica 55mm UVa Filter	XSLEICA55UV	£36
Manfrotto MN327 RC2 Tripod Head	XSMAN327RC2708	£96
Marshall V-LCD70XP HDMI Monitor	XHMAR70XP017	£360
Marshall V-LCD70XP HDMI Monitor	XHMAR70XP017.1	£360
Nikon MB-D11 Battery Grip	XHNIKMBD11976	£90
Nikon MB-D12 Battery Grip	XSNIKMBD12014	£180
Nikon MB-D12 Battery Grip	XSNIKMBD12542	£180
Nikon MB-D14 Battery Grip	XSNIKMBD14852	£132

Nikon MB-D16 Battery Grip	XSNIKMBD16061	£168
Nikon WT-7 File Transmitter	XSNIKWT7148	£594
Gantry Support System	-	£45
Pocket Wizard Flex TT5 Canon Fit	XSPWTT5CAN783	£120
Pocket Wizard Mini TT1 for Canon	XSPWTT1278	£96
Pocket Wizard Plus II Transceiver	XHPWTRPL11408	£42
Pocket Wizard Plus III Set of 2	XSPW111X2770	£150
Pocket Wizard Pre-release Cable Canon Fit	XSPWCANCAB	£12
Aquatech Blimp for EOS 1D Mark III & IV	XSAQUA1D1V040	£510
Aquatech Blimp for Nikon D4	XSAQSHADD4	£480
Aquatech BT160N Tube for Nikkor 24-70mm f/2.8G	XSAQBT160N	£198
Aquatech BT160N Tube for Nikkor 70-200mm f2.8	XSAQBTR215N	£220
Aquatech Shadow Blimp for EOS 1DX	XSAQSHAD1DX	£456
Aquatech Shadow Blimp for EOS 1DX	XSAQUA1DX197	£594
Aquatech Tube for Nikkor 70-200mm f/2.8	XSAQUA70200454	£228
Aquatech Tube for Nikkor 70-200mm f/2.8	XSAQUA70200454A	£228
Jacobsen Blimp & Tube for Nikon D3/D4	XSJACD3123	£480
Canon G1X	XHCANG1X459	£300
Leica M-P (240)	XSLEIMP877	£2,994
Canon 580EX II Speedlite	XSCAN580EX11796	£240
Nikon SB-900 Speedlight	XSNIKSB900089	£180
Nikon SB-910 Speedlight	XSNIKSB910200	£252
Nikon SB-910 Speedlight	XSNIKSB910661	£258
Nissin i40 Flashgun for Sony A7	XSNISI40096	£107
Elinchrom 18cm Grid Set	XHELGRIDSET18	£30
Elinchrom Quadra Lead Battery	XSELQUBATT353	£60
Elinchrom Quadra Lead Battery	XSELQUBATT698	£60
Elinchrom Quadra to EL Adapter	XSELIQELADAPT	£42
Elinchrom Ranger Quadra Charger	XSELQUCH1	£48
Elinchrom Skyport Trigger & Skyport Wi-Fi	XSELISKY123	£48
Profoto 12v Battery for Acute	XHPROFBATT214	£18
Profoto 12v Battery for Acute	XHPROFBATT889	£18
Profoto Air Remote	XSPROAIRREM662	£145
Profoto Compact 600R Flash Head	XHPROFCOM600659	£360
Profoto Compact 600R Flash Head	XHPROFCOM600738	£360
Profoto D1 1000 Air head	XSPROD11000836	£750
Profoto D1 250/250 Air Kit (inc. Remote)	XSPROD1KIT131	£1,248
Profoto D1 500 Air head	XSPROD1500176	£625
Fuji X-E1	XSFUJXE1290	£180
Fuji X-Pro1	XSFUJXPRO1219	£270
Fuji X-T1	XSFUJXT1341	£528
Fuji XE-2	XSFUJXE2245	£282
Rode Blimp Kit	XSRODBLKIT1	£120